

# 789/787B ProcessMeter™

## Quick Reference Guide


### ⚠ Warning

To prevent possible electrical shock, fire, or personal injury, read the "789/787B Safety Information" before you use this Product.


📖 Consult user documentation.

Go to [www.fluke.com](http://www.fluke.com) to register your product and find more information.


Ω




🔊




mA/A





~ V V mV




### Measurement MIN MAX



### Fuse




🔋







### Good Diode




### Good Diode




### Bad Diode




### Bad Diode




### Output Source



### Output Simulate



### Supplying Loop Power (789 only)



→ = conventional current flow.